

FROSTED VINYL INSTALL PROCEDURE

1

Clean glass well, using a razor blade to remove dust if necessary.



2

Wet either another panel of glass or a nearby wall and stick vinyl to the surface so that the backing is facing you. Peel the backing, revealing the adhesive side. Spray both the vinyl and the glass that it's being applied to with rapid tac. Remove vinyl from the surface and stick to the glass, adhesive side to the glass. Check for level if necessary.

3

Squeegee horizontally from the centre out, starting at the top and working down, angling the squeegee so the rapid tac doesn't get pushed back up to where you just squeegeed (start lightly pushing at first). Go over the vinyl again with the squeegee, pushing harder this time, to get any remaining liquid out. After allowing a sufficient amount of time to dry, trim to the edges of the glass, or to desired location.



4

Clean vinyl and glass with glass cleaner. Wipe up any liquid left on the floor.